

您設計產品時的好朋友！



[Forum: Wireless Product \(WiFi, Bluetooth, ..\)](#)

Topic: RN4871 容易變磚

Subject: Re: RN4871 容易變磚

作者: cyshay

2017年08月07日 11:44:51

You must put a 10uF across VBATT and GND. Otherwise, the module will be very unstable. You need to redesign the circuit. Please redesign it and let us review the circuit before you build new PCB.

Thanks.

Martin