



[Forum: 8-bit PIC](#)

Topic: PIC10F220 怎麼設定振盪器頻率

Subject: Re: PIC10F220 怎麼設定振盪器頻率

作者: jason680

2017年07月09日 01:10:04

spec中

REGISTER 8-1: CONFIG: CONFIGURATION WORD

bit 11-5 Unimplemented: Read as '0'

...

bit0 IOSCS: Internal Oscillator Frequency Select bit

1 = 8 MHz

0 = 4 MHz

## 8.2 Oscillator Configurations

### 8.2.1 OSCILLATOR TYPES

The PIC10F220/222 devices are offered with internal oscillator mode only.

&#8226; INTOSC: Internal 4/8 MHz Oscillator