

您設計產品時的好朋友！



[Forum: 8-bit PIC \(請註明使用元件編號\)](#)

Topic: PIC10F220 怎麼設定振盪器頻率

Subject: Re: PIC10F220 怎麼設定振盪器頻率

作者: jason680

2017年07月09日 01:10:04

spec中

REGISTER 8-1: CONFIG: CONFIGURATION WORD

bit 11-5 Unimplemented: Read as '0'

...

bit0 IOSCFS: Internal Oscillator Frequency Select bit

1 = 8 MHz

0 = 4 MHz

8.2 Oscillator Configurations

8.2.1 OSCILLATOR TYPES

The PIC10F220/222 devices are offered with internal oscillator mode only.

• INTOSC: Internal 4/8 MHz Oscillator