

# **Section 5. Flash Programming**

## HIGHLIGHTS

This section of the manual contains the following topics:

5.1	Introduction	
5.2	Table Instruction Operation	
5.3	Control Registers	
5.4	Run-Time Self-Programming (RTSP)	
5.5	Register Map	5-15
5.6	Design Tips	
5.7	Related Application Notes	5-17
5.8	Revision History	

**Note:** This family reference manual section is meant to serve as a complement to device data sheets. Depending on the device variant, this manual section may not apply to all dsPIC33F/PIC24H devices.

Please consult the note at the beginning of the "Flash Program Memory" chapter in the current device data sheet to check whether this document supports the device you are using.

Device data sheets and family reference manual sections are available for download from the Microchip Worldwide Web site at: http://www.microchip.com

## 5.1 INTRODUCTION

This section describes the technique for programming Flash program memory. The dsPIC33F/PIC24H families of devices have an internal programmable Flash memory for executing user codes. There are two methods to program this memory:

- Run-Time Self-Programming (RTSP)
- In-Circuit Serial Programming<sup>™</sup> (ICSP<sup>™</sup>)

This section describes RTSP programming, which is performed by the user-assigned software.

ICSP is performed using a serial data connection to the device and allows faster programming than RTSP. The ICSP protocol is defined in the *"dsPIC33F/PIC24H Flash Programming Specification"* (DS70152), which can be downloaded from the Microchip web site.

## 5.2 TABLE INSTRUCTION OPERATION

The table instructions provide one method of transferring data between the program memory space and the data memory space of dsPIC33F/PIC24H devices. This section provides a summary of the table instructions used during programming of the Flash program memory. There are four basic table instructions:

- TBLRDL: Table Read Low
- TBLRDH: Table Read High
- TBLWTL: Table Write Low
- TBLWTH: Table Write High

The TBLRDL instruction is used to read from bits <15:0> of program memory space. The TBLWTL instruction is used to write to bits <15:0> of program memory space. TBLRDL and TBLWTL can access program memory in Word or Byte mode.

The TBLRDH and TBLWTH instructions are used to read or write to bits <23:16> of program memory space. TBLRDH and TBLWTH can access program memory in Word or Byte mode. Because the program memory is only 24 bits wide, the TBLRDH and TBLWTH instructions can address an upper byte of program memory that does not exist. This byte is called the "phantom byte". Any read of the phantom byte will return 0x00. A write to the phantom byte has no effect.

The 24-bit program memory can be regarded as two side-by-side 16-bit spaces, with each space sharing the same address range. Therefore, the TBLRDL and TBLWTL instructions access the "low" program memory space (PM<15:0>). The TBLRDH and TBLWTH instructions access the "high" program memory space (PM<31:16>). Any reads or writes to PM<31:24> will access the phantom (unimplemented) byte. When any of the table instructions are used in Byte mode, the Least Significant bit (LSb) of the table address will be used as the byte select bit. The LSb determines which byte in the high or low program memory space is accessed.

Figure 5-1 shows how the program memory is addressed using the table instructions. A 24-bit program memory address is formed using bits <7:0> of the TBLPAG register and the effective address (EA) from a W register specified in the table instruction. The 24-bit program counter is shown in Figure 5-1 for reference. The upper 23 bits of the EA are used to select the program memory location.

For the Byte mode table instructions, the LSb of the W register EA is used to select which byte of the 16-bit program memory word is addressed. A '1' selects bits <15:8>. A '0' selects bits <7:0>. The LSb of the W register EA is ignored for a table instruction in Word mode.

In addition to the program memory address, the table instruction also specifies a W register (or a W register pointer to a memory location) that is the source of the program memory data to be written or the destination for a program memory read. For a table write operation in Byte mode, bits <15:8> of the source working register are ignored.





## 5.2.1 Using Table Read Instructions

Table reads require two steps:

- · An address pointer is set up using the TBLPAG register and one of the W registers
- The program memory contents at the address location may be read

#### 5.2.1.1 READ WORD MODE

The code sequence shown in Example 5-1 shows how to read a word of program memory using the table instructions in Word mode.

#### Example 5-1: Read Word Mode

	; Set up th	ne address pointer to program	space	
	MOV	<pre>#tblpage(PROG_ADDR),W0</pre>	; get table page value	
	MOV	W0, TBLPAG	; load TBLPAG register	
	MOV	<pre>#tbloffset(PROG_ADDR),W0</pre>	; load address LS word	
i	; Read the	program memory location		
	TBLRDH	[W0],W3	; Read high byte to W3	
	TBLRDL	[WO],W4	; Read low word to W4	

#### 5.2.1.2 READ BYTE MODE

In the code sequence shown in Example 5-2, the post-increment operator on the read of the low byte causes the address in the working register to increment by one. This sets EA<0> to a '1' for access to the middle byte in the third write instruction. The last post-increment sets W0 back to an even address, pointing to the next program memory location.

**Note:** The tblpage() and tbloffset() directives are provided by the Microchip assembler for the dsPIC33F/PIC24H. These directives select the appropriate TBLPAG and W register values for the table instruction from a program memory address value. For more information, refer to the *"MPLAB<sup>®</sup> Assembler Linker and Utilities for PIC24 MCUs and dsPIC<sup>®</sup> DSCs User's Guide"* (DS51317).

5

#### Example 5-2: Read Byte Mode

;	Set up the a	ddress pointer to program	space	
	MOV	<pre>#tblpage(PROG_ADDR),W0</pre>	;	get table page value
	MOV	W0, TBLPAG	;	load TBLPAG register
	MOV	<pre>#tbloffset(PROG_ADDR),W0</pre>	;	load address LS word
;	Read the pro	gram memory location		
	TBLRDH.B	[W0],W3	;	Read high byte to W3
	TBLRDL.B	[WO++],W4	;	Read low byte to W4
	TBLRDL.B	[W0++],W5	;	Read middle byte to W5

#### 5.2.1.3 TABLE WRITE HOLDING BUFFERS

**Note:** Some dsPIC33F/PIC24H devices do not have multiple holding buffers. Refer to the "Flash Program Memory" section in the specific device data sheet for availability.

Table write instructions do not write directly to the non-volatile program memory. Instead, the table write instructions load holding buffers that store the write data. The multiple holding buffers are not memory mapped and can be accessed only using table write instructions. When all the holding buffers are loaded, the memory programming operation is started by executing a special sequence of instructions.

The dsPIC33F/PIC24H Flash program memory is segmented into pages (512 instruction words) and rows (64 instruction words).

The dsPIC33F/PIC24H family of devices support 64 holding registers to program one row of memory at a time. The memory logic decides which set of write buffers to load based on the address value in the table write instruction.

#### 5.2.1.4 WRITE WORD MODE

The sequence shown in Example 5-3 can be used to write a single program memory latch location in Word mode.

#### Example 5-3: Writing a Single Program Memory Latch Location in Word Mode

;	Setup the a	ddress pointer to program space
	MOV	<pre>#tblpage(PROG_ADDR),W0 ; get table page value</pre>
	MOV	WO,TBLPAG ; load TBLPAG register
	MOV	<pre>#tbloffset(PROG_ADDR),W0 ; load address LS word</pre>
;	Load write	data into W registers
	MOV	#PROG_LOW_WORD,W2
	MOV	#PROG_HI_BYTE,W3
;	Perform the	table writes to load the latch
	TBLWTL	W2,[W0]
	TBLWTH	W3,[W0++]

In Example 5-3, the content of the upper byte of W3 does not matter because this data will be written to the phantom byte location. W0 is post-incremented by two after the second TBLWTH instruction in preparation for the write to the next program memory location. For devices without multiple holding buffers, a complete Flash program cycle must be done before writing to the next programming location.

#### 5.2.1.5 WRITE BYTE MODE

The code sequence shown in Example 5-4 can be used to write a single program memory latch location in Byte mode.

Example 5-4:	Writing a Single Program Memory	/ Latch Location in Byte Mode

;	Setup the	address pointer to program s	spac	ce	
	MOV	<pre>#tblpage(PROG_ADDR),W0</pre>	;	get table page value	
	MOV	W0, TBLPAG	;	load TBLPAG register	
	MOV	<pre>#tbloffset(PROG_ADDR),W0</pre>	;	load address LS word	
;	Load data	into working registers			
	MOV	#LOW_BYTE,W2			
	MOV	#MID_BYTE,W3			
	MOV	#HIGH_BYTE,W4			
;	Write data	a to the latch			
	TBLWTH.E	W4,[W0]	;	write high byte	
	TBLWTL.E	W2, [W0++]	;	write low byte	
	TBLWTL.E	W3, [W0++]	;	write middle byte	

In Example 5-4, the post-increment operator on the write to the low byte causes the address in W0 to increment by one. This sets EA<0> = 1 for access to the middle byte in the third write instruction. The last post-increment sets W0 back to an even address pointing to the next program memory location. For devices without multiple holding buffers, a complete Flash program cycle must be done before writing to the next programming location.

## 5.3 CONTROL REGISTERS

Two Special Function Registers (SFRs) are used to program Flash memory erase and write operations: NVMCON and NVMKEY.

The Flash Memory Control register (NVMCON) controls which memory segments are to be erased, erase cycle, fuse/Flash operation, word or row programming, write status, bulk erase and start of programming cycle. For devices without multiple holding buffers, only word programming is allowed.

The Nonvolatile Memory Key register (NVMKEY) is a write-only register that is used for protection from unintended Flash operations. To start a programming or erase sequence, the user must consecutively write 0x55 and 0xAA to the NVMKEY register.

## 5.3.1 NVMCON Register

The NVMCON register is the primary control register for Flash and program/erase operations. This register selects whether an erase or program operation will be performed and can start the program or erase cycle.

The NVMCON register is shown in Register 5-1. The lower byte of NVMCON configures the type of NVM operation that is performed.

## 5.3.2 NVMKEY Register

The NVMKEY register (Register 5-2) is a write-only register used to prevent accidental writes or erasures of Flash memory. To start a programming or erase sequence, the following steps must be considered sequentially:

- 1. Write 0x55 to NVMKEY.
- 2. Write 0xAA to NVMKEY.
- 3. Execute two NOP instructions.

After this sequence, a write will be allowed to the NVMCON register for one instruction cycle. In most cases, the user-assigned application needs to set the WR bit in the NVMCON register to start the program or erase instruction cycle. Interrupts should be disabled during the key sequence. Example 5-5 shows how the key sequence is performed.

#### Example 5-5: NVMKEY Key Sequence

PUSH MOV IOR	SR #0x00E0,W0 SR	; Disable interrupts, if enabled
MOV MOV MOV BSET NOP NOP	#0x55,W0 W0, NVMKEY #0xAA,W0 W0, NVMKEY NVMCON,#WR	; NOP not required ; Start the program/erase cycle
POP	SR	; Re-enable interrupts

For more information, refer to 5.4.2 "Flash Programming Operations".

		DAA( 0(1)					
R/SU-U(*			0-0	0-0	0-0	0-0	0-0
	WREN	WRERR	_				
DIL 15							DIL O
U-0	R/W-0 <sup>(1)</sup>	U-0	U-0	R/W-0 <sup>(1)</sup>	R/W-0 <sup>(1)</sup>	R/W-0 <sup>(1)</sup>	R/W-0 <sup>(1)</sup>
	ERASE	_			NVMOP	<3:0> <sup>(2,3)</sup>	
bit 7							bit 0
Legend:		SO = Settable	only bit				
R = Readal	ole bit	W = Writable b	oit	U = Unimple	mented bit, read	as '0'	
-n = Value a	at POR	'1' = Bit is set		'0' = Bit is cl€	eared	x = Bit is unkr	iown
bit 15	WR: Write Co 1 = Initiates a cleared 0 = Program	ontrol bit a Flash memory by hardware af or erase operat	/ program or ter the opera ion is comple	erase operation is complete ete and inactive	on. The operatic e	on is self-timed	and the bit is
bit 14	WREN: Write	e Enable bit					
	1 = Enable Fl 0 = Inhibit Fla	lash program/er ash program/era	ase operatio se operation	ns s			
bit 13	WRERR: Wri	te Sequence Er	ror Flag bit				
	1 = An impro on any s 0 = The prog	per program or set attempt of th ram or erase or	erase seque ne WR bit) peration comr	nce attempt or	termination has	occurred (bit is	set
bit 12-7	Unimplemen	nted: Read as '(	)'				
bit 6	ERASE: Eras	se/Program Ena	ble bit				
	1 = Perform t 0 = Perform t	he erase operat	tion specified	l by NVMOP<3 ied by NVMOP	:0> on the next P<3:0> on the ne	WR command	nd
bit 5-4	Unimplemen	ited: Read as '(	)'	,			
bit 3-0	NVMOP<3:0	>: NVM Operati	on Select bit	S <sup>(2,3)</sup>			
	If ERASE = 1						
	1111 <b>= Mem</b>	ory bulk erase c	peration				
	1110 = Rese	rved	ont and ECS	Configuration	register		
	1100 <b>= Eras</b> e	e Secure Segme	ent and FSS	Configuration	register		
	1011 <b>= Rese</b>	rved		-	-		
	0011 = No op 0010 = Mem	peration	operation				
	0001 = No or	peration	operation				
	0000 <b>= Erase</b>	e a single Confi	guration regis	ster byte			
	If ERASE = 0	):					
	1111 <b>= No o</b>	peration					
	1110 = Rese	rved					
	1100 <b>= No o</b>	peration					
	1011 <b>= Rese</b>	rved					
	0011 = Mem	ory word progra	m operation				
	0001 = Mem	ory row program	n operation				
	0000 <b>= Prog</b> r	ram a single Co	nfiguration re	egister byte			
Note 1: 2:	All other combina	reset only on a itions of NVMOF	a POR. P<3:0> are u	nimplemented.			

Register 5-1: **NVMCON: Flash Memory Control Register** 

5

Flash Programming

U-0	U-0	U-0	U-0	U-0	U-0	U-0	U-0
_	—	_	_	—	_	_	_
bit 15							bit 8
W-0	W-0	W-0	W-0	W-0	W-0	W-0	W-0
			NVMK	(EY<7:0>			
bit 7							bit 0
Legend:		SO = Settable	e only bit				
R = Readable bit		W = Writable	bit	U = Unimpler	mented bit, rea	ad as '0'	
-n = Value at F	POR	'1' = Bit is set	t	'0' = Bit is cle	ared	x = Bit is unkr	nown

## Register 5-2: NVMKEY: Nonvolatile Memory Key Register

bit 15-8 Unimplemented: Read as '0'

bit 7-0 **NVMKEY<7:0>:** Key Register (write-only) bits

## 5.4 RUN-TIME SELF-PROGRAMMING (RTSP)

RTSP allows the user-assigned application to modify Flash program memory contents. RTSP is accomplished using TBLRD (table read) and TBLWT (table write) instructions, and the NVM Control registers. With RTSP, the user-assigned application can erase program memory eight rows (64 \* 8 = 512 instructions) at a time and can write program memory data a single row (64 instructions) at a time (on devices with multiple holding buffers, or a single instruction simultaneously for devices without multiple holding buffers).

## 5.4.1 RTSP Operation

The dsPIC33F/PIC24H Flash program memory array is organized into rows of 64 instructions or 192 bytes. RTSP allows the user-assigned application to erase blocks of eight rows (512 instructions) simultaneously and to program 64 instructions at a time (on devices with multiple holding buffers, or a single instruction at a time for devices without multiple holding buffers). The 8-row erase blocks and single-row write blocks are edge-aligned, from the beginning of program memory, on boundaries of 1536 bytes and 192 bytes.

The program memory implements holding buffers on some devices that can contain 64 instructions of programming data. Prior to the programming operation, the write data must be loaded into the buffers. The instruction words loaded must be from a group of 64 boundaries. To successfully program the Flash memory, the address written by the last TBLWTL or TBLWTH instruction must belong to the row that is intended to be programmed. For devices without multiple holding buffers, single word programming is the only option available.

The basic sequence for RTSP is to set up a Table Pointer, and then perform a series of TBLWTL and TBLWTH instructions to load the buffers. Programming is performed by setting the control bits in the NVMCON register. A total of 64 TBLWTL and TBLWTH instructions are required to load the instructions when multiple holding buffers are present. A different sequence is followed on devices without multiple holding buffers. Only one set of TBLWTL and TBLWTH instructions are required to load a single buffer, and then programming is performed by setting the control bits in the NVMCON register.

All the table write operations are single-word writes (two instruction cycles), because only the buffers are written. A programming cycle is required for programming each word or row.

## 5.4.2 Flash Programming Operations

A program or erase operation is necessary for programming or erasing the internal Flash program memory in RTSP mode. The program or erase operation is automatically timed by the device (for timing information, refer to the device data sheet). Setting the WR bit (NVMCON<15>) starts the operation. The WR bit is automatically cleared when the operation is finished.

The CPU stalls (waits) until the programming operation is finished. The CPU will not execute any instructions or respond to interrupts during this time. If any interrupts occur during the programming cycle, it will remain pending until the cycle completes. If a Power-On Reset (POR) or Brown-Out Reset (BOR) occurs, the programming or erase operation will be aborted and user should execute the programming or erase operation again after the reset. If any other reset occurs while executing a programming or erase operation (WDTO, IOPUWR, MCLR, SWR, CM, or TRAPR) the result will remain pending until the RTSP cycle completes.

### 5.4.2.1 FLASH ROW PROGRAMMING ALGORITHM

Flash row programming is only possible on devices with multiple holding buffers.

The user-assigned application can program one row of Flash program memory (64 instruction words). To perform this, it is necessary to erase a page (512 instruction words) containing the desired row.

The general process is as follows:

- 1. Read one page (512 instruction words) of Flash program memory and store it into data RAM as a data "image". The RAM image must be read from an even 512-word program memory address boundary.
- 2. Update the RAM data image with the new program memory data.
- 3. Erase the Flash program memory page.

Programming

- a) Set up the NVMCON register to erase one page of Flash program memory.
- b) Select the page for an erase operation by performing a dummy table write to any location in the page.
- c) Disable interrupts.
- d) Write the key sequence to the NVMKEY register to enable the erase.
- e) Set the WR bit. This will start the erase cycle.
- f) The CPU will stall for the duration of the erase cycle.
- g) The WR bit is cleared when the erase cycle ends.
- h) Re-enable interrupts.
- 4. Load the row (64 instruction words) of instruction words from RAM into the write buffers using a table write operation.
- 5. Program the row (64 instruction words) in Flash program memory.
  - a) Set up the NVMCON register to program one row of Flash program memory.
  - b) Disable interrupts.
  - c) Write the key sequence to the NVMKEY register to enable the program cycle.
  - d) Set the WR bit. This will start the program cycle.
  - e) The CPU will stall for the duration of the program cycle.
  - f) The WR bit is cleared by the hardware when the program cycle ends.
  - g) Re-enable interrupts.
- 6. Repeat steps 4 through 6 to program all eight rows in the program memory page.
- 7. Repeat steps 1 through 7, as needed, to program the desired amount of Flash program memory.
  - **Note 1:** The user should remember that the minimum amount of program memory that can be erased using RTSP is 512 instruction word locations. Therefore, it is important that an image of these locations be stored in general purpose RAM before an erase cycle is initiated.
    - **2:** A row or word in Flash program memory should not be programmed more than twice before being erased.

#### 5.4.2.2 FLASH SINGLE WORD PROGRAMMING ALGORITHM

This algorithm is available for devices with multiple or single holding buffers.

The user-assigned application can program one word of Flash program memory (that is, 1 instruction word).

The general process is as follows:

- 1. Load the word (1 instruction word) from RAM into the write latch using a table write operation.
- 2. Program the instruction word in Flash program memory.
  - a) Set up the NVMCON register to program one word of Flash program memory.
  - b) Disable interrupts.
  - c) Write the key sequence to the NVMKEY register to enable the program cycle.
  - d) Set the WR bit. This will start the program cycle.
  - e) The CPU will stall for the duration of the program cycle.
  - f) The WR bit is cleared by the hardware when the program cycle ends.
  - g) Re-enable interrupts.
- Repeat steps 1 and 2 as needed to program the desired amount of Flash program memory.

#### 5.4.2.3 ERASING ONE PAGE OF FLASH

The code sequence shown in Example 5-6 can be used to erase a page (512 instructions) of program memory. The NVMCON register is configured to erase one page of program memory. A dummy table write to any location in the page selects the address of the row to be erased. The

program memory must be erased at an "even" 512 instruction word address boundary. Therefore, the 10 Least Significant bits of the table write program memory address have no effect when a page is erased.

The erase operation is initiated by writing a key sequence to the NVMKEY register before setting the WR control bit (NVMCON<15>). The key sequence needs to be executed in the exact order as shown, without interruption. Therefore, interrupts should be disabled prior to writing the sequence.

Two NOP instructions should be inserted in the code at the point where the CPU will resume operation. Finally, interrupts can be enabled (if required).

Example 5-6: Erasing a Page of Flash Program Memory

;	Perform dummy	y table write to the Page to be erased.
	MOV	<pre>#tblpage(PROG ADDR),W0</pre>
	MOV	W0,TBLPAG
	MOV	<pre>#tbloffset(PROG ADDR),W0</pre>
	TBLWTL	w0,[w0]
;	Setup NVMCON	to erase one page of Program Memory
	MOV	#0x4042,W0
	MOV	W0,NVMCON
;	Disable inter	rrupts while the KEY sequence is written
	PUSH	SR
	MOV	#0x00E0,W0
	IOR	SR
;	Write the KEY	Y Sequence
	MOV	#0x55,W0
	MOV	W0,NVMKEY
	MOV	#0xAA,W0
	MOV	W0,NVMKEY
;	Start the era	ase operation
	BSET	NVMCON, #WR
;	Insert two No	DPs after the erase cycle (required)
	NOP	
	NOP	
; F	Re-enable inte	errupts, if needed
	POP	SB

#### 5.4.2.4 LOADING WRITE BUFFERS

This action only applies to devices with multiple holding buffers.

The write buffers are used as a storage mechanism between the user application table writes and the actual row programming sequence. Example 5-7 provides the sequence of instructions that can be used to load 64 write buffers (64 instruction words). Sixty-four TBLWTL and 64 TBLWTH instructions are needed to load the write buffers for programming a row of Flash memory.

The row of 64 instruction words does not necessarily have to be written in sequential order. The 7 Least Significant bits of the table write address determine which of the buffers will be written. However, all 64 instruction words should be written for each programming cycle to overwrite old data.

Table write program memory addresses are captured to select the address of the row to be programmed. The program memory must be programmed at an "even" 64 instruction word address boundary. In effect, the 7 Least Significant bits of the table write operation select the write buffers to program the instruction word within the row. They have no effect when a row is programmed.

Note: The code shown in Example 5-7 is the Load\_Write\_Latch code that is referred in subsequent examples.

#### Example 5-7: Loading Write Buffers

; Set ı	np a poi MOV MOV	nter to the first program memory location to be written. #tblpage(PROG_ADDR),W0 W0,TBLPAG
	MOV	<pre>#tbloffset(PROG_ADDR),W0</pre>
; Perfo ; WO is ; next	orm the s increm instruc MOV MOV	TBLWT instructions to write the latches ented in the TBLWTH instruction to point to the tion location. #64,W3 #ram image.W1
loop:	TBLWTL TBLWTH DEC BRA	[W1++],[W0] [W1++],[W0++] W3,W3 NZ,loop

#### 5.4.2.5 SINGLE ROW PROGRAMMING EXAMPLE

This example only applies to devices with multiple holding buffers.

The NVMCON register is configured to program one row of Flash memory. The program operation is initiated by writing a key sequence to the NVMKEY register before setting the WR control bit (NVMCON<15>). The key sequence needs to be executed in the exact order as shown in Example 5-8, without interruption. Therefore, interrupts should be disabled prior to writing the sequence.

Two NOP instructions should be inserted in the code at the point where the CPU will resume operation. Finally, interrupts can be enabled (if required).

Example 5-8: Single Row Programming

;	Setup NVMCON	to write 1 row of program memory
	MOV	#0x4001,W0
	MOV	W0,NVMCON
;	Load the 32	program memory write latches
	CALL	Load_Write_Latch(1)
;	Disable inte	rrupts, if enabled
	PUSH	SR
	MOV	#0x00E0,W0
	IOR	SR
;	Write the KE	Y sequence
	MOV	#0x55,W0
	MOV	W0,NVMKEY
	MOV	#0xAA,W0
	MOV	W0,NVMKEY
;	Start the pr	ogramming sequence
	BSET	NVMCON, #WR
;	Insert two N	OPs after programming
	NOP	
	NOP	
;	Re-enable in	terrupts, if required
	POP	SR
1		

Note: For more information, see 5.4.2.4 "Loading Write Buffers".

#### 5.4.2.6 PROGRAMMING ONE WORD OF FLASH MEMORY

Assuming the user-assigned application has erased the Flash location to be programmed, use table write instructions to write an instruction word (24-bit) into the write latch. The 7 Least Significant bits of the table write operation select the write latch to program the instruction word within the row.

The TBLPAG register is loaded with the 8 Most Significant bits of the Flash address. The 16 Least Significant bits of the Flash address are automatically captured internally when the table write is executed to program the word during program operation.

The NVMCON register is configured to program one word of Flash memory. The program operation is initiated by writing a key sequence to the NVMKEY register before setting the WR control bit (NVMCON<15>). The key sequence needs to be executed in the exact order as shown in Example 5-9, without interruption. Therefore, interrupts should be disabled prior to writing the sequence.

Two NOP instructions should be inserted in the code at the point where the CPU will resume operation. Finally, interrupts can be enabled (if required).

;	Setup a pointer to data Program Memory											
		MOV	<pre>&gt;V #tblpage(PROG_ADDR),W0</pre>									
		MOV	W0, TBLPAG									
		MOV	<pre>#tbloffset(PROG_ADDR),W0</pre>									
;	Perfo	Perform the TBLWT instructions to write the latches										
		MOV	#LOW_WORD_N,W2									
		MOV	#HIGH BYTE N,W3									
		TBLWTL	W2,[W0]									
		TBLWTH	W3,[W0++]									
;	Setup	NVMCON	for programming one word to data Program Memory									
		MOV	#0x4003,W0									
		MOV	W0,NVMCON									
;	; Disable interrupts while the KEY sequence is written											
		PUSH	SR									
		MOV	#0x00E0,W0									
		IOR	SR									
;	Write	the key	y sequence									
		MOV	#0x55,W0									
		MOV	W0,NVMKEY									
		MOV	#OxAA,WO									
		MOV	W0,NVMKEY									
;	Start	the wr	ite cycle									
		BSET	NVMCON, #WR									
;	;Re-enable interrupts, if needed											
		POP	SR									

Example 5-9: Programming One Word of Flash Memory

## 5.4.3 Writing to Device Configuration Registers

Run-Time Self-Programming (RTSP) can be used to write to the device Configuration registers. RTSP allows each Configuration register to be individually rewritten without performing an erase cycle. Caution must be exercised when writing the Configuration registers because they control critical device operating parameters, such as the system clock source, PLL multiplication ratio and WDT enable.

The procedure for programming a Device Configuration register is similar to the procedure for programming Flash program memory, except only TBLWTL instructions are required. This is because the upper eight bits in each Device Configuration register are unused. Furthermore, bit 23 of the table write address must be set to access the Configuration registers. For more

information on device configuration registers, refer to the **Section 25. "Device Configuration"** (DS70194) in the *"dsPIC33F/PIC24H Family Reference Manual"* and the **"Special Features"** chapter of the specific device data sheet.

- **Note 1:** Writing to device configuration registers is not available in all devices. Please refer to the specific device data sheet to determine the modes that are available according to the device-specific NVMOP<3:0> bits definition.
  - 2: While performing RTSP on device Configuration registers, the device must be operating using the Internal FRC Oscillator (without PLL). If the device is operating from a different clock source, a clock switch to the Internal FRC Oscillator (NOSC<2:0> = '000') must be performed prior to performing RTSP operation in device Configuration registers.
  - 3: If the Primary Oscillator Mode Select bits (POSCMD<1:0>) in the Oscillator Configuration register (FOSC) are being reprogrammed to a new value, ensure that the Clock Switching Mode bits (FCKSM<1:0>) in the FOSC register have an initial programmed value of '00', prior to performing this RTSP operation.

#### 5.4.3.1 CONFIGURATION REGISTER WRITE ALGORITHM

- 1. Write the new configuration value to the table write latch using a TBLWTL instruction.
- 2. Configure NVMCON for a Configuration register write (NVMCON = 0x4000).
- 3. Disable interrupts, if enabled.
- 4. Write the key sequence to NVMKEY.
- 5. Start the write sequence by setting WR (NVMCON<15>).
- 6. CPU execution will resume when the write is finished.
- 7. Re-enable interrupts, if needed.

Example 5-10 provides the code sequence that can be used to modify a device Configuration register.

#### Example 5-10: Configuration Register Write Code Example

```
; Set up a pointer to the location to be written.
      MOV #tblpage(CONFIG ADDR),W0
           W0,TBLPAG
      MOV
      MOV #tbloffset(CONFIG ADDR),W0
; Get the new data to write to the configuration register
      MOV #ConfigValue,W1
; Perform the table write to load the write latch
      TBLWTL W1, [W0]
; Configure NVMCON for a configuration register write
      MOV
              #0x4000,W0
      MOV
              W0,NVMCON
; Disable interrupts, if enabled
      PUSH SR
      MOV
              #0x00E0,W0
      IOR
             SR
; Write the KEY sequence
      MOV #0x55,W0
      MOV
              W0,NVMKEY
      MOV
              #0xAA,W0
      MOV
              W0,NVMKEY
; Start the programming sequence
      BSET NVMCON, #WR
; Insert two NOPs after programming
      NOP
      NOP
; Re-enable interrupts, if required
       POP
              SR
```

## 5.5 REGISTER MAP

A summary of the registers associated with Flash Programming is provided in Table 5-1.

## Table 5-1: Flash Programming Registers

File Name	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	All Resets
NVMCON	WR	WREN	WRERR	—	—	_	—	—	_	ERASE	—	_	NVMOP<3:0>				0000
NVMKEY	_	—	—	—	—	_	—	—	NVMKEY<7:0>								0000

Legend: x = unknown value on Reset, — = unimplemented, read as '0'. Reset values are shown in hexadecimal.

## 5.6 DESIGN TIPS

# Question 1: I cannot get the device to program or erase properly. My code appears to be correct. What could be the cause?

Answer: Interrupts should be disabled when a program or erase cycle is initiated to ensure that the key sequence executes without interruption. Interrupts can be disabled by raising the current CPU priority to level 7.

The code examples in this chapter disable interrupts by saving the current SR register value on the stack, then ORing the value 0x00E0 with SR to force IPL<2:0> = 111. If no priority level 7 interrupts are enabled, the DISI instruction provides another method to temporarily disable interrupts while the key sequence is executed.

## 5.7 RELATED APPLICATION NOTES

This section lists application notes that are related to this section of the manual. These application notes may not be written specifically for the dsPIC33F/PIC24H product families, but the concepts are pertinent and could be used with modification and possible limitations. The current application notes related to the Flash Programming module include the following:

#### Title

Application Note #

No related application notes are available.

**Note:** Please visit the Microchip web site (www.microchip.com) for additional Application Notes and code examples for the dsPIC33F/PIC24H family of devices.

## 5.8 REVISION HISTORY

## **Revision A (February 2007)**

This is the initial released version of this document.

## **Revision B (February 2007)**

Minor edits throughout the document.

## **Revision C (December 2009)**

This version of the document was created by combining the dsPIC33F and PIC24H Flash Programming family reference manual sections into a single document with the following updates:

- Added a shaded note at the beginning of the section, which provides information on complementary documentation
- Added Note 1 and Note 2 to 5.4.3 "Writing to Device Configuration Registers"
- Additional minor corrections such as language and formatting updates were incorporated throughout the document

## Revision D (April 2010)

This version of the document contains the following updates:

- · Added a shaded note to 5.2.1.3 "Table Write Holding Buffers"
- Added a sentence related to devices without multiple holding buffers to the last paragraph of **5.2.1.4** "Write Word Mode" and **5.2.1.5** "Write Byte Mode" and to the second paragraph of **5.3** "Control Registers"
- Added Note 3 to the Flash Memory Control register (Register 5-1)
- Updated the first paragraph of 5.4 "Run-Time Self-Programming (RTSP)"
- Updated the second and third paragraphs of 5.4.1 "RTSP Operation"
- Updated the first paragraph of 5.4.2.1 "Flash Row Programming Algorithm"
- Added the new section 5.4.2.2 "Flash Single Word Programming Algorithm"
- Added a shaded note to 5.4.2.4 "Loading Write Buffers"
- · Add a sentence to the first paragraph of 5.4.2.5 "Single Row Programming Example"
- Added a new Note 1 to the shaded note in **5.4.3** "Writing to Device Configuration Registers"
- Added the new section 5.5 "Register Map"

#### Note the following details of the code protection feature on Microchip devices:

- · Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

## QUALITY MANAGEMENT SYSTEM CERTIFIED BY DNV ISO/TS 16949:2002

#### Trademarks

The Microchip name and logo, the Microchip logo, dsPIC, KEELOQ, KEELOQ logo, MPLAB, PIC, PICmicro, PICSTART, PIC<sup>32</sup> logo, rfPIC and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

FilterLab, Hampshire, HI-TECH C, Linear Active Thermistor, MXDEV, MXLAB, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Application Maestro, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, dsSPEAK, ECAN, ECONOMONITOR, FanSense, HI-TIDE, In-Circuit Serial Programming, ICSP, Mindi, MiWi, MPASM, MPLAB Certified logo, MPLIB, MPLINK, mTouch, Octopus, Omniscient Code Generation, PICC, PICC-18, PICDEM, PICDEM.net, PICkit, PICtail, REAL ICE, rfLAB, Select Mode, Total Endurance, TSHARC, UniWinDriver, WiperLock and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2010, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.



ISBN: 978-1-60932-145-1

Microchip received ISO/TS-16949:2002 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.



## WORLDWIDE SALES AND SERVICE

#### AMERICAS

Corporate Office 2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277 Technical Support: http://support.microchip.com Web Address: www.microchip.com

Atlanta Duluth, GA Tel: 678-957-9614 Fax: 678-957-1455

Boston Westborough, MA Tel: 774-760-0087 Fax: 774-760-0088

Chicago Itasca, IL Tel: 630-285-0071 Fax: 630-285-0075

**Cleveland** Independence, OH Tel: 216-447-0464 Fax: 216-447-0643

**Dallas** Addison, TX Tel: 972-818-7423 Fax: 972-818-2924

Detroit Farmington Hills, MI Tel: 248-538-2250 Fax: 248-538-2260

Kokomo, IN Tel: 765-864-8360 Fax: 765-864-8387

Los Angeles Mission Viejo, CA Tel: 949-462-9523 Fax: 949-462-9608

Santa Clara Santa Clara, CA Tel: 408-961-6444 Fax: 408-961-6445

Toronto Mississauga, Ontario, Canada Tel: 905-673-0699 Fax: 905-673-6509

#### ASIA/PACIFIC

Asia Pacific Office Suites 3707-14, 37th Floor Tower 6, The Gateway Harbour City, Kowloon Hong Kong Tel: 852-2401-1200 Fax: 852-2401-3431 Australia - Sydney

Tel: 61-2-9868-6733 Fax: 61-2-9868-6755

**China - Beijing** Tel: 86-10-8528-2100 Fax: 86-10-8528-2104

**China - Chengdu** Tel: 86-28-8665-5511 Fax: 86-28-8665-7889

**China - Chongqing** Tel: 86-23-8980-9588 Fax: 86-23-8980-9500

**China - Hong Kong SAR** Tel: 852-2401-1200 Fax: 852-2401-3431

China - Nanjing Tel: 86-25-8473-2460

Fax: 86-25-8473-2470 China - Qingdao Tel: 86-532-8502-7355 Fax: 86-532-8502-7205

**China - Shanghai** Tel: 86-21-5407-5533 Fax: 86-21-5407-5066

**China - Shenyang** Tel: 86-24-2334-2829 Fax: 86-24-2334-2393

**China - Shenzhen** Tel: 86-755-8203-2660 Fax: 86-755-8203-1760

**China - Wuhan** Tel: 86-27-5980-5300 Fax: 86-27-5980-5118

**China - Xian** Tel: 86-29-8833-7252 Fax: 86-29-8833-7256

**China - Xiamen** Tel: 86-592-2388138 Fax: 86-592-2388130

**China - Zhuhai** Tel: 86-756-3210040 Fax: 86-756-3210049

### ASIA/PACIFIC

India - Bangalore Tel: 91-80-3090-4444 Fax: 91-80-3090-4123

**India - New Delhi** Tel: 91-11-4160-8631 Fax: 91-11-4160-8632

India - Pune Tel: 91-20-2566-1512 Fax: 91-20-2566-1513

**Japan - Yokohama** Tel: 81-45-471- 6166 Fax: 81-45-471-6122

**Korea - Daegu** Tel: 82-53-744-4301 Fax: 82-53-744-4302

Korea - Seoul Tel: 82-2-554-7200 Fax: 82-2-558-5932 or 82-2-558-5934

Malaysia - Kuala Lumpur Tel: 60-3-6201-9857 Fax: 60-3-6201-9859

**Malaysia - Penang** Tel: 60-4-227-8870 Fax: 60-4-227-4068

Philippines - Manila Tel: 63-2-634-9065 Fax: 63-2-634-9069

Singapore Tel: 65-6334-8870 Fax: 65-6334-8850

Taiwan - Hsin Chu Tel: 886-3-6578-300 Fax: 886-3-6578-370

**Taiwan - Kaohsiung** Tel: 886-7-536-4818 Fax: 886-7-536-4803

Taiwan - Taipei Tel: 886-2-2500-6610 Fax: 886-2-2508-0102

**Thailand - Bangkok** Tel: 66-2-694-1351 Fax: 66-2-694-1350

#### EUROPE

Austria - Wels Tel: 43-7242-2244-39 Fax: 43-7242-2244-393 Denmark - Copenhagen Tel: 45-4450-2828 Fax: 45-4485-2829

France - Paris Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

**Germany - Munich** Tel: 49-89-627-144-0 Fax: 49-89-627-144-44

Italy - Milan Tel: 39-0331-742611 Fax: 39-0331-466781

Netherlands - Drunen Tel: 31-416-690399 Fax: 31-416-690340

**Spain - Madrid** Tel: 34-91-708-08-90 Fax: 34-91-708-08-91

**UK - Wokingham** Tel: 44-118-921-5869 Fax: 44-118-921-5820